

RAMI7509B TRIPOD SET-UP INSTRUCTIONS

Fold the three (3) legs of the tripod into the down position.

Turn the locking plate so the legs are locked in place and cannot be folded.

Secure the locking plate by tightening the three (3) thumbs screws.

Thread the eyebolt into the threaded hole in the bottom of the antenna base.

Mount the CBA antenna to the pivot plate using the hardware provided.

Place the anchor stake in the center of the three legs and hammer into the ground at approximately 60°.

Attach the clip at the end of the rope of the tensioner assembly to the anchor stake.

Attach the other clip of the tensioner assembly to the eyebolt in the antenna base.

Pull rope taut and secure with tensioner by placing rope into slot.

Note: Thumb screws are NOT removable. When loosening the locking plate, turn thumb screws ¼ to ½ turn. Do not force to loosen.

Roof Top Mount:

When mounting the tripod on a hard surface such as a roof top or concrete, place the roof top mount included on the ground instead of hammering anchor stake into ground.

Place sand bags or something with significant weight in the 10" round plate of the mount.

Then clip the tensioner assembly to the eyebolt of the mount.

