



RAMI, Inc.  
Grand Haven, MI 49417  
(616) 842-9450  
www.rami.com

AV-75& AV-75(-F)  
Broad Band General Aviation Antenna

Frequency range: 864-930 MHz

Installation Instructions

- 1.) Mounting locations should be at least 18" from any other metal protrusions and on as flat a surface as possible on the aircraft top & belly.
- 2.) Using the template provided, drill two mounting holes and one hole for the connector.
- 3.) Mount the antenna by placing the rubber pad provided between the antenna base and aircraft skin. Insert hardware provided as shown below and tighten all mounting screws securely to provide good electrical contact. Antenna with FLARM logo (P/N: AV-75(-F)) is mounted on top of the aircraft. Antenna without FLARM logo (P/N: AV-75) is mounted on belly of the aircraft.
- 4.) Connect the antenna using RG-58/U or similar 50 ohm coax cable with a BNC type male connector attached to the antenna end of the cable (not supplied). Terminate the other end of the cable with a suitable connector to mate with the aircraft equipment.

